



POSE EN APPLIQUE SUR LA FAÇADE PAR VISSAGE / WALL MOUNTED INSTALLATION - DRILLING REQUIRED
MONTAGE AUF DER FASSADE DURCH SCHRAUBEN / INSTALACIÓN DE TIPO APLIQUE EN LA FACHADA CON ATORNILLADO

- FR** | Mettre en place les chevilles (non fournies), ainsi que la moustiquaire.
- EN** | Fix the brackets (not supplied), and position the fly screen.
- DE** | Befestigen Sie die Haken (werden nicht mitgeliefert) und anschließend das Fliegengitter.
- ES** | Coloque los tornillos (no vienen incluidos) y la mosquitera.

